

Instructions for Disinfectant Mats



Set up

- Place black absorbent pad inside blue waterproof sleeve
- Place mat where it is to be used on a level surface
- Use the table below to work out how much solution you will need
- Pre mix disinfectant or foot care product to required strength
- Pour gently over black absorbent pad
- Fill pad until it is saturated and liquid appears when you lightly put your foot on the pad, leave for 5 minutes and top up

Mat Dimensions	Mat Use	Capacity	Top Up
60 x 90 x 4 cm	Personnel disinfection	10 to 15 litres	As required
230 x 47 x 4 cm	Sheet foot care	25 to 30 litres	Every 150 to 200 sheep passes
180 x 90 x 4 cm	Personnel disinfection	45 to 60 litres	As required
180 x 90 x 4 cm	Cattle foot care	45 to 60 litres	Every 75 to 85 cow passes
4 x 180 x 90 x 4 cm	Vehicle disinfection	45 to 60 litres / mat (180 to 240 litres in total)	As required

Use

- Do not rush animals over the mat—sheep will follow head to tail once started
- Vehicles should drive over the mats at no more than 5 mph

Maintenance

- Top up as required and replenish within effective active time of disinfectant or care product
- Fully clean mat and replenish every week for best results

After use

- Dispose of contents safely
- Remove black pad from sleeve and hose thoroughly and allow to dry
- Store when not in use in a dry area
- The effectiveness of your treatment or care product will diminish if left in a dirty mat.

Instructions for Vehicle Disinfection



To disinfect lorries, vans or cars:

- Arrange four mats as shown in the diagram
- Blue sleeves can be trimmed by up to 10cm to give additional width if necessary
- Follow the set up and use instructions shown overleaf
- Vehicles must not exceed 5 mph when driving over mats

Any questions phone us on 01327 300 395

Buy your mats online at our online shop
www.farmandcountrydirect.co.uk

Intershape Ltd

Michaelmas House, Royal Oak Way North, Daventry, NN11 8PQ

Tel: 01327 300 395

Email: info@intershape.com Web: www.intershape.com